






















- PL** Instrukcja montażu Karta gwarancyjna
- D** Aufbauanleitung der Garantieschein
- GB** Assembly instruction Guarantee certificate
- SK** Návod na montáž Záručný list






C  x20	D  x20	P.  x4	M.  	W3 6x9.5  x8
A  	W1 3.5x16  x8	 		









x2





x2











x4



x4



x4



AB=CD

